



Circle Cutter

You now have the flexibility to make a perfect circle in any size that you need. When you've cut 1,500 circles, just replace the blade and keep going! Learn how to use this brand new tool in the instructions below. Plus, watch a video when you scan this QR code with the camera on your smartphone.







Circle Cutter Straight Blade #659583 | \$6.00

Includes 1 Straight Blade

Ready to order? Ask your Creative Memories Advisor or visit the website.



CIRCLE CUTTER

May 2021

HOW TO READ THE MEASUREMENTS

Each mark equals .2". For example, use this marking to draw a 4.6" circle.



Gray markings are used for drawing circles.

White markings are for cutting circles and individual notches equal .2" increments (metric on opposite side).

Each mark equals .2". For example, use this marking to cut an 11.4" circle.

HOW TO CUT A CIRCLE



Step 1

Twist the white sizing dial (counter-clockwise) to loosen and slide it to desired cut diameter using the white markings. Lock it into place by tightening (clockwise).



Step 2

On a 13x13 cutting mat (sold separately), position your paper and place the Circle Cutter on top. Press and hold the sizing dial to keep it in place.




Step 3

With your other hand, push in the white button on the blade housing and press down the blade housing to engage the cutting blade.



Step 4

While pressing down the blade housing and holding the sizing dial in place, rotate the blade housing 360° to cut a circle. If needed, you may backtrack to cut any missed spots.



Step 5

Release pressure from the blade housing and sizing dial to remove the Circle Cutter from your paper.

HOW TO DRAW A CIRCLE



Step 1

Twist the white sizing dial (counter-clockwise) to loosen and slide it to desired circle diameter using the gray markings. Lock it into place by tightening (clockwise).



Step 2

Place the Circle Cutter in desired location on top of paper. Press and hold the sizing dial to keep it in place.



Step 3

With your other hand, insert a CM Pen (fine tip only) into the pen holder.



Step 4

While holding the sizing dial in place, draw a circle with your pen by rotating it 360° over your paper. If needed, you may backtrack to fill in any missed spots.



Step 5

Remove the pen and release pressure from the sizing dial to remove the Circle Cutter from your paper.

HOW TO REPLACE THE CUTTING BLADE



Step 1

Press the blue button on the blade housing to swing it open.



Step 2

Pull out the old blade and replace with a new one — orientation does not matter.



Step 3

Close blade housing.